

CENTAMAX-Coupling

Assembly and operating instructions

004S-00800...18000-SS00

M004-00018-EN

Rev. 1



Contents

1	General remarks	5
2	Safety	6
2.1	Safety remarks	6
2.1.1	Signal words	6
2.1.2	Pictograms	7
2.2	Qualification of deployed personnel	7
2.3	Intended application.....	7
2.4	Application not in compliance with the intended use	9
3	Delivery, transport, storage and disposal	10
3.1	Delivery	10
3.2	Transport.....	10
3.3	Storage	10
3.3.1	Storage location.....	11
3.3.2	Storage of couplings / flexible elements	11
3.4	Disposal.....	11
4	Technical description	12
4.1	Characteristics.....	12
4.2	Specifications	12
5	Alignment of the units being connected	13
5.1	Axial alignment.....	13
5.2	Radial alignment.....	14
5.3	Angular alignment.....	15
6	Mounting	16
6.1	General assembly instructions	16
6.2	Mounting the hubs	18
6.2.1	Mounting the hub with cylindrical bore and keyway	18
6.2.2	Mounting the hub with conical oil interference fit.....	20
6.2.3	Mounting the hub with cylindrical oil interference fit	22
6.2.4	Mounting the CENTALOC clamping hub	24
6.3	Aligning the units.....	25
6.4	Positioning the rubber element into the pre-mounted adapter (D).....	26
6.5	Mounting the pre-mounted adapter with rubber element (E)	27
6.6	Mounting the rubber element	28
6.6.1	Mounting the rubber element (coupling sizes 0800...4000 and 8000...18000)	28
6.6.2	Mounting the rubber element (coupling sizes 5000 and 7000)	29
6.7	After completed mounting.....	30



7	Operation.....	31
7.1	Operating faults, root causes and remedy	31
8	Care and maintenance	32
8.1	Work to be performed	32
8.1.1	Cleaning the coupling	32
8.1.2	Visual inspection of the coupling	32
8.1.3	Visual inspection of the rubber elements	33
8.1.4	Inspection of the screw connections	33
8.2	Replacing defective parts	33
9	Dismantling	34
9.1	General dismantling instructions	34
9.2	Dismantling the rubber element.....	35
9.2.1	Dismantling the rubber element (sizes 0800...4000 and 8000...18000	35
9.2.2	Dismantling the rubber element (sizes 5000 and 7000)	35
9.3	Dismantling the pre-mounted adapter with rubber element (E).....	35
9.4	Removing the rubber element	35
9.5	Dismantling the hubs (if necessary)	36
9.5.1	Dismantling the hub with cylindrical bore and keyway	36
9.5.2	Dismantling the hub with conical oil interference fit.....	36
9.5.3	Dismantling the hub with cylindrical oil interference fit	38
9.5.4	Dismantling the CENTALOC clamping hub	40
9.6	Reassembling the coupling.....	40
10	Wearing and spare parts.....	41
11	Annex	42
11.1	CENTA data sheet D013-016 (unlubricated screw connections).....	42
11.2	CENTA data sheet D004-900 Declaration of incorporation according to the EC Machinery Directive 2006/42/EC, Appendix II B.....	43



Index of illustrations

Fig. 5-1 Axial misalignment.....	13
Fig. 5-2 Radial misalignment.....	14
Fig. 5-3 Angular misalignment.....	15
Fig. 6-1 Mounting the hub with cylindrical bore and keyway	18
Fig. 6-2 Mounting the hub with conical oil interference fit	20
Fig. 6-3 Mounting the hub with cylindrical oil interference fit	22
Fig. 6-4 Mounting the CENTALOC clamping hub	24
Fig. 6-5 Positioning the rubber element into the pre-mounted assembly (D)	26
Fig. 6-6 Mounting the pre-mounted adapter with rubber element (E)	27
Fig. 6-7 Mounting the rubber element (coupling sizes 0800...4000 and 8000...18000	28
Fig. 6-8 Mounting the rubber element (coupling sizes 5000 and 7000)	29
Fig. 8-1 Visual inspection at the rubber elements.....	33
Fig. 9-1 Dismantling the hub with cylindrical oil interference fit	39

Index of tables

Table 2-1 Shape and size of ventilation holes	8
Table 6-1 Tightening torques for threaded pins.....	19
Table 7-1 Troubleshooting table	31

Index of formulas

Formula 5-1 Calculated dimension S_w	15
--	----



1 General remarks

These assembly and operating instructions form a constituent part of the coupling delivery and must be kept in an easily accessible place at all times.

CENTA products are developed and produced to quality standard DIN EN ISO 9001:2000.

In the interests of further development, CENTA reserves the right to make technical changes.



IMPORTANT

CENTA is unable to accept liability for damage and operating faults caused by failure to observe the operating instructions.

These operating instructions are protected under copyright to CENTA Antriebe Kirschey GmbH.

In case of technical questions, please enquire with our head office:

**CENTA Antriebe
Kirschey GmbH**
Bergische Strasse 7
42781 Haan
GERMANY
Phone +49-2129-912-0
Fax +49-2129-2790
centa@centa.de
www.centa.info

2 Safety

The purpose of these operating instructions is to enable users to:

- use the coupling safely and correctly
- maximize efficiency
- ensure that care and maintenance are carried out correctly

For this reason, these operating instructions must be thoroughly read and understood prior to work on and with the coupling.

WARNING



Injury and material damage can occur as a result of:

- Failure to adhere to the safety and accident prevention regulations valid at the relevant installation site

The safety and accident prevention regulations valid at the installation site in question must be adhered to when performing any of the tasks described in these operating instructions.

2.1 Safety remarks

In these operating instructions, safety remarks are indicated by a pictogram and a signal word.

2.1.1 Signal words

The following signal words are used in the safety remarks:

DANGER

Denotes the immediate threat of danger.
If not prevented, fatal or extremely serious injuries can result.

WARNING

Denotes a potentially dangerous situation.
If not prevented, fatal or extremely serious injuries can result.

CAUTION

Denotes a potentially dangerous situation.
If not prevented, minor injuries and/damage to property may result.

IMPORTANT

Denotes application tips and particularly useful information. This is not a signal word denoting a dangerous or damaging situation.

2.1.2 Pictograms

Possible pictograms in the safety precautions:



Warning of a hazardous area



Do not switch



Use protective gloves



Use protective goggles

2.2 Qualification of deployed personnel

All the work described in these operating instructions may only be performed by authorized persons with adequate training and instruction.

WARNING	
	<p>Injury and material damage can occur as a result of:</p> <ul style="list-style-type: none"> ▪ Work at the coupling which is not described in these instructions <p>Only carry out work which is described in these operating instructions.</p>

2.3 Intended application

WARNING	
	<p>Injury and material damage can occur as a result of:</p> <ul style="list-style-type: none"> ▪ Application not in compliance with the intended use <p>The couplings are intended exclusively for use in accordance with the relevant design. They may only be used under the specified conditions.</p>

WARNING



Injuries can occur as a result of:

- Contact with rotating parts

Shield the coupling in accordance with the applicable accident prevention regulations with an enclosure.

Exception:

The coupling is encased by the driving and driven units.

The scope of delivery provided by CENTA does not include a protective enclosure.

This enclosure must fulfil the following criteria:

- Provide protection against persons gaining access to rotating parts
- Restrain any rotating parts which may be work loose
- Guarantee sufficient ventilation for the coupling

This enclosure must be made of stable steel components. In order to ensure adequate ventilation for the coupling, the enclosure must be fitted with regular openings. For safety reasons, these openings must not exceed the dimensions outlined in table 2-1.

Component	Circular openings [mm]	Rectangular openings [mm]
Top of the enclosure	Ø 8	□ 8
Side elements of the enclosure	Ø 8	□ 8

Table 2-1 Shape and size of ventilation holes

The enclosures must be positioned a minimum of 15 mm distant from rotating parts. The enclosure must be electrically conductive and be included in the equipotential bonding.

Before commencing long-term operation, the plant must successfully complete a test run.

2.4 Application not in compliance with the intended use**WARNING****Injury and material damage can occur as a result of:**

- Inadmissibly high torque
- Inadmissibly high or low speeds
- Exceeding the specified ambient temperature
- Inadmissible ambient medium
- Inadmissible coupling enclosure
- Exceeding the admissible overall misalignment values

Only use the coupling for the specified application.

CENTA bears no liability for damage resulting from application not in compliance with the intended use of the equipment.

Should there be a change of plant parameters, the coupling design must be reviewed by CENTA (address see chapter 1).

3 Delivery, transport, storage and disposal

3.1 Delivery

After delivery, the coupling:

- must be checked for completeness and correctness of the delivery.
- must be examined for possible transport damage (which must be reported immediately to the carrier).

3.2 Transport

CAUTION	
	<p>Injury and material damage can occur as a result of:</p> <ul style="list-style-type: none"> ▪ Incorrect transportation of couplings <p>Ensure that the coupling is correctly transported.</p>
CAUTION	
	<p>Material damage to coupling components can occur as a result of:</p> <ul style="list-style-type: none"> ▪ Contact with sharp-edged objects <p>Protect coupling components for transportation. Only hoist coupling components with nylon belts or ropes. Always cushion parts when supporting them from below.</p>

Following transportation damage:

- Check the coupling carefully for damage.
- Consult the manufacturer (Address see chapter 1).

3.3 Storage

CAUTION	
	<p>Material damage to elastic elements and rubber parts can occur as a result of:</p> <ul style="list-style-type: none"> ▪ Incorrect storage <p>These parts must be stored laid flat and so they cannot distort, and protected from ozone, heat, light, moisture and solvents.</p>
 IMPORTANT	
<p>Rubber parts are marked where possible with their production date. From this date, they may only be stored for a maximum of 5 years.</p>	

3.3.1 Storage location

Requirements imposed on the storage location:

- Moderately ventilated and low in dust
- Dry (max. 65% humidity)
- Temperature stabilized (-10°C to +25°C)
- Free of ozone-producing devices such as light sources and electric motors
- Free of UV light sources and direct sunlight
- Do not store solvents and disinfectants, fuels or lubricants, acids, chemicals etc. in the same location

For more details, refer to DIN 7716.

3.3.2 Storage of couplings / flexible elements

- Unpack the parts.
- Check the packaging for damage. Replace if necessary.
- Check that the wax protection on steel components is intact. If necessary, patch or renew.
- Package the parts (for prolonged periods of storage, enclose desiccant and weld into film).
- Place the parts into storage.

3.4 Disposal

RECYCLING	
	Ensure safe, environmentally responsible disposal of operating supplies and exchange parts. For this, locally provided recycling facilities and regulations must be utilized.

For disposal, the coupling parts must be separated where possible and sorted according to material type.

4 Technical description

4.1 Characteristics

- Highly torsional elasticity / backlash-free
- Linear curve
- Due to different shore hardness levels, the torsional rigidity can be adjusted to vibration-related requirements
- Dampens vibrations and impacts - compensates axial, radial and angular alignment errors
- Low-wear – durability – operational reliability – low maintenance
- Compact, short design – connection dimensions in accordance with SAE J 620 or for connection of two shafts
- Free axial movement
- All-round ventilation (cooling) of the rubber washer
- Suitable for high speeds
- Large admissible bores
- Simple mounting - axial plug-in capability
- Temperature-resistant

4.2 Specifications

Admissible ambient temperatures:

NR: -45°C to +80°C (temporary maximum temperature 100°C)

SI: -45°C to +130°C

Ensure that suitable ventilation is provided in the mounting area of the coupling so that the admissible ambient temperature is not exceeded.

For further technical details, see the catalogue and the dimensions contained in the drawings.

5 Alignment of the units being connected

IMPORTANT

- The units should be aligned during assembly.
- The overall misalignment is composed of the misalignment and the operating misalignment. The permissible overall misalignment values can be found in the catalogue and must not be exceeded.
Align the units that are to be connected as accurately as possible. In this way, a long service life for the coupling and maximum operating misalignment values can be achieved.
After completion of assembly, check the alignment of the coupling again and if necessary correct.

5.1 Axial alignment

Determine the axial misalignment (see Fig. 5-1).

- Take installation length **L** from the installation drawing.
- Align the units (installation dimension = **$L \pm \Delta K_A$**).

Permissible axial alignment tolerance:

$$\Delta K_{A \max} = 1,0 \text{ mm}$$




Fig. 5-1 Axial misalignment

5.2 Radial alignment

CAUTION



Material damage to elastically installed motors can occur as a result of:

- Disregard during alignment of the extent by which the motor bearing settles

During vertical alignment, take into account the extent by which the motor bearing settles. Please enquire about specifications for the degree of settling from the motor manufacturer or motor bearing manufacturer.

Measure the radial misalignment with a dial gauge (see Fig. 5-2).

- Attach the dial gauge to the hub.
- Set the sensor of the dial gauge radially against the centering.
- Turn the hub with dial gauge and flywheel slowly by 360°.
- Align the units (calculated deviation $\leq \Delta K_R \text{ max}$).

Permissible radial alignment tolerance:

$\Delta K_R \text{ max} = 0,5 \text{ mm}$




Fig. 5-2 Radial misalignment

5.3 Angular alignment

Measure the angular misalignment with a dial gauge (see Fig. 5-3).

- Attach the dial gauge to the hub.
- Position the sensor of the dial gauge radially against flat surface at a distance R.
- Turn the hub with dial gauge and flywheel slowly by 360°.

The maximum dial gauge deflection must not exceed the value $2xS_w$ at any point. The permissible tolerance $S_{w \max}$ should be calculated according to formula 5-1 below.

- Align the units (calculated deviation $\leq \Delta K_{W \max}$).

Permissible angular alignment tolerance:

$$\Delta K_{W \max} = 0,15^\circ$$




Fig. 5-3 Angular misalignment

$$S_w = R \cdot \tan(\Delta K_w)$$

$$S_w = R \cdot 0,0026$$

Formula 5-1 Calculated dimension S_w

6 Mounting

6.1 General assembly instructions

Any work method which impairs the safety of the coupling is prohibited.
The user undertakes to notify the manufacturer immediately of any changes occurring at the coupling which could impair safety (address see chapter 1).

WARNING	
	<p>Injuries can occur as a result of:</p> <ul style="list-style-type: none"> ▪ Contact with rotating parts <p>Before starting work at the coupling, switch off the plant and secure against unintentional start-up.</p>
WARNING	
	<p>Injury and material damage can occur as a result of:</p> <ul style="list-style-type: none"> ▪ Assembly of the coupling in the wrong sequence <p>Only ever assemble the coupling in the described sequence.</p>
WARNING	
	<p>Injury and material damage can occur as a result of:</p> <ul style="list-style-type: none"> ▪ Falling coupling components <p>Secure coupling components against falling to the floor.</p>
CAUTION	
	<p>Material damage to coupling components can occur as a result of:</p> <ul style="list-style-type: none"> ▪ Contact with sharp-edged objects <p>Protect coupling components for transportation. Only hoist coupling components with nylon belts or ropes. Always cushion parts when supporting them from below.</p>
CAUTION	
	<p>Material damage can occur as a result of:</p> <ul style="list-style-type: none"> ▪ Soiled joint surfaces <p>The surfaces that are to be joined must be free of dirt, preservatives and lubricants.</p>

CAUTION

Material damage to coupling components can occur as a result of:

- Anaerobic adhesives (e.g. Loctite) used for screw locking

This type of screw locking medium may not be in contact with rubber parts.

**IMPORTANT**

- Screw preparation and tightening torque levels in accordance with CENTA data sheet D013-013 (see chapter 11.1).
- Use suitable lifting devices for assembly.
- The following assembly stages are described for coupling 004S-07000+12000-SS00.
- Part illustration and marking may differ slightly from installation drawing and delivery state.

6.2 Mounting the hubs

- Mount the hub as appropriate for the supplied design (see installation drawing):
 - Mounting the hub with cylindrical bore and keyway, see chapter 6.2.1.
 - Mounting the hub with conical oil interference fit, see chapter 6.2.2.
 - Mounting the hub with cylindrical oil interference fit, see chapter 6.2.3.
 - Mounting the CENTALOC clamping hub, see chapter 6.2.4.

6.2.1 Mounting the hub with cylindrical bore and keyway




Fig. 6-1 Mounting the hub with cylindrical bore and keyway

Item	Info	Designation	Remark
2/12		Hub	
22		Threaded pin	If ordered
A/B		Shaft	Customer part
	a	Face of the shaft	
	b	Face of the hub	

CAUTION



Material damage can occur as a result of:

- Incorrect heating of the hubs/flange hubs
- Heat the hubs/flange hubs steadily in an oil bath, a fan oven, on an electric hot plate, either inductive or with a flame (ring burner).

CAUTION



Injuries can occur as a result of:

- Hot coupling components
- Use suitable protective gloves.



IMPORTANT

Face of shaft must not protrude to face of hub. Otherwise radial replacement of other coupling parts is not guaranteed.

- Heat the hub (2/12) to a temperature of 170° - 200°C.
- Push the hub (2/12) onto the shaft (A/B).

CAUTION




Material damage can occur as a result of:

- Hot hubs/flange hubs
- Before further mounting of hubs/flange hubs, allow them to cool to ambient temperature.

- Prepare the threaded pin (22) for mounting. Degrease the thread.
- Apply a screw locking medium (e.g. Loctite) to the thread of the threaded pin (22).
- Secure the hub (2/12) with the threaded pin (22; size acc. the installation drawing, tightening torque see table below).

Threaded pin	M6	M8	M10	M12	M14	M16	M20
Tightening torque [Nm]	7	16	30	50	70	120	200

Table 6-1 Tightening torques for threaded pins

6.2.2 Mounting the hub with conical oil interference fit

Fig. 6-2 Mounting the hub with conical oil interference fit

Item	Info	Designation	Remark
2/12		Hub	
19		Screw plug	G $\frac{1}{4}$ or G $\frac{3}{4}$ see installation drawing
A/B		Shaft	Customer part
	a	Face of shaft	
	b	Face of hub	
	c	Thread	G $\frac{1}{4}$ or G $\frac{3}{4}$ see installation drawing

- Lightly oil the cone of the shaft (A/B).
- Push the hub (2/12) onto the shaft (A/B).
- Remove the screw plug (19) from the hub (2/12).

WARNING**Injury and material damage can occur as a result of:**

- Non-compliance with the operating instructions for the hydraulic pumps

Before carrying out work with the hydraulic pumps, do not fail to read their operating instructions. Only ever work with hydraulic pumps as described in their operating instructions.

WARNING**Injury and material damage can occur as a result of:**

- Hydraulic fluid spraying out

Use protective goggles.

**IMPORTANT**

We recommend the following mounting fluids:

- For mounting:
Oil with a viscosity 300 mm²/s at 20°C, e.g. SKF LHM300
- For dismantling:
Oil with a viscosity 900 mm²/s at 20°C, e.g. SKF LHDF900

- Connect the pump (**p_{max} = 3000 bar**) for expanding the hub (2/12) to the thread G¹/₄ or G³/₄ (c).
- Screw the pump for pushing on the hub to the shaft.
- Build up the oil pressure to push on the hub.

WARNING**Material damage can occur as a result of:**

- Insufficient expanding pressure in the hub

If the expanding pressure is too low, the necessary pushing pressure is too high.

- Build up the oil pressure for expanding the hub.
- Build up the oil pressure alternately until the lift path (p up) of the hub (2/12) is reached (for p up and reference faces, see installation drawing).
- Decrease the oil pressure for expanding the hub.
- Remove the pump for expanding the hub from the hub (2/12).
- Maintain the oil pressure for pushing on the hub for one hour.
- Decrease the oil pressure for pushing on the hub.

- Remove the pump for pushing on the hub from the shaft.
- Turn the hub (2/12), drain oil out of the thread G $\frac{1}{4}$ or G $\frac{3}{4}$ (c) and dispose correctly.
- Screw the screw plug (19) into the hub (2/12).

 IMPORTANT

Do not place a load on the hub for 24 hours.

 IMPORTANT

Face of shaft must not protrude to face of hub. Otherwise radial replacement of other coupling parts is not guaranteed.

6.2.3 Mounting the hub with cylindrical oil interference fit




Fig. 6-3 Mounting the hub with cylindrical oil interference fit

Item	Info	Designation	Remark
2/12		Hub	
19		Screw plug	3 x 120° offset
A/B		Shaft	Customer part
	a	Face of shaft	
	b	Face of hub	
	c	Thread G $\frac{1}{4}$	3 x 120° offset

CAUTION**Material damage can occur as a result of:**

- Incorrect heating of the hubs/flange hubs

Heat the hubs/flange hubs steadily in an oil bath, a fan oven, on an electric hot plate, either inductive or with a flame (ring burner).

CAUTION**Injuries can occur as a result of:**

- Hot coupling components

Use suitable protective gloves.

- Remove all screw plugs (19) from the hub (2/12).
- Warm the hub (2/12) to a temperature of 280°C - 320°C.
- Push the hub (2/12) onto the shaft (A/B).

**IMPORTANT**

Face of shaft must not protrude to face of hub. Otherwise radial replacement of other coupling parts is not guaranteed.

CAUTION**Material damage can occur as a result of:**

- Hot hubs/flange hubs

Before further mounting of hubs/flange hubs, allow them to cool to ambient temperature.

- Screw all screw plugs (19) into the hub (2/12).


6.2.4 Mounting the CENTALOC clamping hub


Fig. 6-4 Mounting the CENTALOC clamping hub

Item	Info	Designation	Remark
2/12		Hub assembly	Pre-mounted
2.1/12.1		Hub	
2.2/12.2		Threaded pin	
2.3/12.3		Parallel pin DIN7	See installation drawing
2.4/12.4		Parallel pin DIN7	See installation drawing
2.5/12.5		Circlip DIN472	Design of the hub see installation drawing
A/B		Shaft	Customer part
	e	Shaft end	
	f	Back side of circlip	
	h	Shaft shoulder	

- Push the hub assembly (2/12) as appropriate for the supplied design **with / without** circlip (2.5/12.5: see installation drawing) onto the shaft (A/B).
- **with** circlip (2.5/12.5):
Push the hub assembly (2/12) onto the shaft (A/B), until the shaft end (e) touches the back side of the circlip (f).

**IMPORTANT**

Ensure that the hub is correctly positioned on the shaft (against shaft end).
If necessary brace hub with washer against the shaft.

- **without** circlip (2.5/12.5):
Push the hub assembly (2/12) against the shaft shoulder (h).

**IMPORTANT**

Ensure that the hub is correctly positioned on the shaft (against shaft shoulder).
If necessary brace hub with washer against the shaft.

- Secure the hub assembly (2/12) with the parallel pins (2.3/12.3 and 2.4/12.4) and the threaded pins (2.2/12.2, size acc. the installation drawing, tightening torque see chapter 6.2.1, table 6-1).

6.3 Aligning the units

- Align the units to be connected (see chapter 5).

6.4 Positioning the rubber element into the pre-mounted adapter (D)




Fig. 6-5 Positioning the rubber element into the pre-mounted assembly (D)

Item	Info	Designation	Remark
1		Rubber element	
D		Pre-mounted adapter	
E		Pre-mounted adapter with rubber element	
	k	Correct position of the ring	

 IMPORTANT

The tothing on the rubber element must be free of oil and grease.
If necessary, use soap or talcum powder.

- Rotate the rubber element (1) in such a way that it can be pushed into the pre-mounted adapter (D).
- Push the rubber element (1) into the pre-mounted adapter (D).

6.5 Mounting the pre-mounted adapter with rubber element (E)




Fig. 6-6 Mounting the pre-mounted adapter with rubber element (E)

Item	Info	Designation	Remark
2		Hub	
12		Hub	
13		Screw	
E		Pre-mounted adapter with rubber element	

- Push the pre-mounted adapter with rubber element (E) onto the centring of the hub (12).
- Screw the hub (12) to the pre-mounted adapter with rubber element (E) using the screws (13).

6.6 Mounting the rubber element

- Mount the rubber element as appropriate for the coupling size supplied:
 - Mounting the rubber element (sizes 0800...4000 and 8000...18000), see chapter 6.6.1.
 - Mounting the rubber element (sizes 5000 and 7000), see chapter 6.6.2.

6.6.1 Mounting the rubber element (coupling sizes 0800...4000 and 8000...18000)




Fig. 6-7 Mounting the rubber element (coupling sizes 0800...4000 and 8000...18000)

Item	Info	Designation	Remark
1		Rubber element	
2		Hub	
4		Screw	

- Push the rubber element (1) onto the centring of the hub (2).
- Screw the hub (2) to the rubber element (1) using the screws (4).


6.6.2 Mounting the rubber element (coupling sizes 5000 and 7000)


Fig. 6-8 Mounting the rubber element (coupling sizes 5000 and 7000)

Item	Info	Designation	Remark
1		Rubber element	
2		Hub	
4		Screw	
6		Ring	

- Push the ring (6) into the centring of the rubber element (2).
- Push ring (6) along with the rubber element (1) onto the centring of the hub (2).
- Screw the hub (2) and the ring (6) to the rubber element (1) using the screws (4).

6.7 After completed mounting**WARNING****Injury and material damage can occur as a result of:**

- Loose screw connections

Before commissioning, the tightening torque levels of all screws must be checked and corrected if necessary.

Before commencing long-term operation, the plant must successfully complete a test run.

7 Operation

WARNING



Injury and material damage can occur as a result of:

- Worn coupling components

If the running noises change and/or vibrations occur turn the plant off immediately.

Determine the fault and its root cause, and remedy.
The troubleshooting process is simplified by the table in the next chapter.
On principle in case of a fault, an analysis of the entire plant should be performed.

7.1 Operating faults, root causes and remedy

Faults	Possible root causes	Remedy
Prior to all kinds of remedies		<ul style="list-style-type: none"> • Switch off the plant • Disconnect the driving and the driven units
Running noises or vibrations in the unit	Loose screws	<ul style="list-style-type: none"> • Check screw torque levels and correct
Rubber element damaged	Inadmissibly high torque	<ul style="list-style-type: none"> • Replace the rubber element
	Damage due to rotary oscillation: <ul style="list-style-type: none"> • Motor idle running speed too low • Cylinder failure 	
	Inadmissibly high ambient temperature: <ul style="list-style-type: none"> • Embrittlement of the rubber element NR, surface cracks on both sides under 45° 	
After all remedies		<ul style="list-style-type: none"> • Connect the driving and the driven units • Trial run

Table 7-1 Troubleshooting table

In case of uncertainty or if you have questions, please contact our head office (address see chapter 1).

8 Care and maintenance

WARNING

**Injuries can occur as a result of:**

- Contact with rotating parts

Before starting work at the coupling, switch off the plant and secure against unintentional start-up.

- The coupling requires low maintenance, and has to be maintained according to the existing installation situation.
 - At flanged drives:
We recommend a visual inspection if the driving and driven units have to be separated.
 - At non flanged drives:
It is possible to perform a visual inspection during the regular scheduled maintenance intervals for the complete unit. Every 12 month a visual inspection is strictly required.

8.1 Work to be performed

8.1.1 Cleaning the coupling

- Remove any loose dirt from the coupling.

8.1.2 Visual inspection of the coupling

- Inspect the coupling for cracks, chips or missing parts.
- Replace faulty and missing parts.

8.1.3 Visual inspection of the rubber elements



IMPORTANT

Exchange the rubber elements:

- In the event of damage, but at the standard maintenance interval of the engine at the latest.




Fig. 8-1 Visual inspection at the rubber elements

Pay attention to cracks / adherence of rubber and metal parts in the zones marked by arrows (a).

Should the cracks be 3 mm or deeper, the rubber element **must** be exchanged (d).

Wear of 3-4 mm to the round teeth on the load side is admissible (c).

At a standstill, there is a distance of 1-2 mm between the coupling flange and the rubber element. At operational speed, the centrifugal force presses the rubber toothing against the coupling flange (b).

8.1.4 Inspection of the screw connections

- Check the tightening torque levels of all screws and if necessary, correct.

8.2 Replacing defective parts

- Remove the coupling as described in chapter 9.
- Replace wearing parts.
- Mount the coupling as described in chapter 6.

9 Dismantling

9.1 General dismantling instructions

Any work method which impairs the safety of the coupling is prohibited.
The user undertakes to notify the manufacturer immediately of any changes occurring at the coupling which could impair safety (address see chapter 1).

 IMPORTANT	
The coupling is dismantled in reverse order to the assembly process. Please refer to the illustrations in chapter 6.	
WARNING	
	<p>Injuries can occur as a result of:</p> <ul style="list-style-type: none"> ▪ Contact with rotating parts <p>Before starting work at the coupling, switch off the plant and secure against unintentional start-up.</p>
WARNING	
	<p>Injury and material damage can occur as a result of:</p> <ul style="list-style-type: none"> ▪ Dismantling of the coupling in the wrong sequence <p>Only ever dismantle the coupling in the described sequence.</p>
WARNING	
	<p>Injury and material damage can occur as a result of:</p> <ul style="list-style-type: none"> ▪ Falling coupling components <p>Secure coupling components against falling to the floor.</p>
CAUTION	
	<p>Material damage to coupling components can occur as a result of:</p> <ul style="list-style-type: none"> ▪ Contact with sharp-edged objects <p>Protect coupling components for transportation. Only hoist coupling components with nylon belts or ropes. Always cushion parts when supporting them from below.</p>
 IMPORTANT	
Use suitable lifting devices for dismantling.	

9.2 Dismantling the rubber element

- Dismantle the rubber element as appropriate for the supplied design (see installation drawing).
- Dismantling the rubber element (sizes 0800...4000 and 8000...18000), see chapter 9.2.1.
- Dismantling the rubber element (sizes 5000 and 7000), see chapter 9.2.2.

9.2.1 Dismantling the rubber element (sizes 0800...4000 and 8000...18000)

See fig. 6-7:

- Loosen and remove the screws (4) of the connection rubber element (1) and hub (2).
- Pull the rubber element (1) off the centring of the hub (2).

9.2.2 Dismantling the rubber element (sizes 5000 and 7000)

See fig. 6-8:

- Loosen and remove the screws (4) of the connection rubber element (1), hub (2) and ring (6).
- Pull the rubber element (1) along with the ring (6) off the centring of the hub (2).
- Pull the ring (6) out of the centring of the rubber element (1) and remove.

9.3 Dismantling the pre-mounted adapter with rubber element (E)

See Fig. 6-6:

- Loosen the screws (13) of the connection pre-mounted adapter with rubber element (E) and hub (12) and remove.
- Pull the pre-mounted adapter with rubber element (E) off the centring of the hub (12) and remove.

9.4 Removing the rubber element

See Fig. 6-5:

- Pull the rubber element (1) out of the pre-mounted adapter (D) and remove.

9.5 Dismantling the hubs (if necessary)

- Dismantle the hubs as appropriate for the supplied design (see installation drawing).
 - Dismantling the hub with cylindrical bore and keyway, see chapter 9.5.1.
 - Dismantling the hub with conical oil interference fit, see chapter 9.5.2.
 - Dismantling the hub with cylindrical oil interference fit, see chapter 9.5.3.
 - Dismantling the CENTALOC clamping hub, see chapter 9.5.4.

9.5.1 Dismantling the hub with cylindrical bore and keyway

See Fig. 6-1:

- Loosen the threaded pins (8; if existing) and remove off the hub (2).
- Remove the hub (2) from the shaft (A/B).

9.5.2 Dismantling the hub with conical oil interference fit

See Fig. 6-2:

WARNING	
	<p>Injury and material damage can occur as a result of:</p> <ul style="list-style-type: none"> ▪ Non-compliance with the operating instructions for the hydraulic pumps <p>Before carrying out work with the hydraulic pumps, do not fail to read their operating instructions. Only ever work with hydraulic pumps as described in their operating instructions.</p>
WARNING	
	<p>Injury and material damage can occur as a result of:</p> <ul style="list-style-type: none"> ▪ Hydraulic fluid spraying out <p>Use protective goggles.</p>
WARNING	
	<p>Injuries and material damages can occur by:</p> <ul style="list-style-type: none"> ▪ Suddenly loosening hubs <p>Secure the hub with a hydraulic tool against sudden axial loosening.</p>

 **IMPORTANT**

We recommend the following mounting fluids:

- For mounting:
Oil with a viscosity 300 mm²/s at 20°C, e.g. SKF LHMF300
- For dismantling:
Oil with a viscosity 900 mm²/s at 20°C, e.g. SKF LHDF900

- Remove screw plug (19) from hub (2/12).
- Connect the pump to the thread G¼ or G¾ (c) of hub (2/12) to expand the hub.
- Screw the pump to the shaft (A/B), in order to hold the hub.
- Build up oil pressure in order to hold the hub.

WARNING**Material damage can occur as a result of:**

- Too fast increase of the expanding pressure in the hub
- The increase of the expanding pressure may not exceed **35 bar/minute**.

- Slowly build up oil pressure to expand the hub (**p_{max} = 1500 bar**).
- Slowly reduce the oil pressure for holding the hub.
- Slowly reduce the oil pressure for expanding the hub.
- Repeat the above mounting section until the hub is completely released from the shaft.
- Remove the pump for holding the hub from the shaft (A/B).
- Remove pump for expanding the hub from the hub (2/12).
- Turn the hub (2/12), drain oil out of the thread G¼ or G¾ (c) and dispose correctly.
- Screw the screw plug (19) into the hub (2/12).
- Remove the hub (2/12) from the shaft (A/B).

9.5.3 Dismantling the hub with cylindrical oil interference fit**WARNING****Injury and material damage can occur as a result of:**

- Non-compliance with the operating instructions for the hydraulic pumps

Before carrying out work with the hydraulic pumps, do not fail to read their operating instructions. Only ever work with hydraulic pumps as described in their operating instructions.

WARNING**Injury and material damage can occur as a result of:**

- Hydraulic fluid spraying out

Use protective goggles.

WARNING**Injury and material damage can occur as a result of:**

- Large quantity of hydraulic fluid spraying out

Close the hub with a cover.
Take up leaked hydraulic fluid.

**IMPORTANT**

We recommend the following mounting fluids:

- For mounting:
Oil with a viscosity 300 mm²/s at 20°C, e.g. SKF LHM300
- For dismantling:
Oil with a viscosity 900 mm²/s at 20°C, e.g. SKF LHDF900

- Remove the screw plugs (19) from the hub (2/12) (see Fig. 6-3).




Fig. 9-1 Dismantling the hub with cylindrical oil interference fit

Item	Info	Designation	Remark
2/12		Hub	
A/B		Shaft	Customer part
F		Force in tensile direction	
G		Cover with fasteners	Customer part
P		Connection for hydraulic pump	P1, P2, P3
	a	Face of shaft	
	x	Oilgroove	x1, x2, x3

- Mount the cover (G) to the hub (2/12).
- Connect the high-pressure pumps with the connections (P1, P2 and P3).
- Slowly build up the oil pressure for expanding the hub (**p_{max} = 1500 bar**).
- Pull the hub (2/12) with force (F) continuously in shown direction, until the hub (2/12) is dismantled.
- Remove the high-pressure pumps from the hub (2/12).
- Dismantle the cover (G) from the hub (2/12).
- Pick up leaked hydraulic fluid and dispose properly.
- Screw the screw plugs (19) into the hub (2/12, see fig. 6-3).

9.5.4 Dismantling the CENTALOC clamping hub

See Fig. 6-4:

- Loosen the threaded pins (2.2/12.2).
- Remove the hub assembly (2/12) from the shaft (A/B).

9.6 Reassembling the coupling

- Reassemble the coupling as described in chapter 6.

10 Wearing and spare parts**WARNING****Injury and material damage can occur as a result of:**

- Mounting and/or utilization of non-original CENTA parts
- Never use parts from other manufacturers.

A stock of the most important wearing and spare parts is the most important condition to ensure that the coupling is functional and ready for operation at all times.

We only provide a warranty for CENTA original parts.

Wearing part of this coupling:

- Rubber element

When ordering a spare, specify:

- Order no.
- Coupling order no.
- Drawing no.



11 Annex

11.1 CENTA data sheet D013-016 (unlubricated screw connections)

Validity:

For all non-dynamically stressed screw connections with **not lubricated** shank bolts in accordance with ISO 4014, ISO 4017 and ISO 4762 (DIN 912) with metric standard thread in accordance with DIN ISO 262, unless other specifications are given on CENTA documents.

Preparation of parts that are to be screwed together:

The joining areas must be free of dirt, preservatives and lubricants.

Preparation of screws that ARE NOT secured with liquid screw locking medium:

Use screws as delivered.

Preparation of screws that ARE secured with liquid screw locking medium:

Remove all grease from the thread.

Screw tightening method:

Screw in (by hand with torque wrench).

d	Thread size			d	Thread size		
	Strength class	Tightening torques			Strength class	Tightening torques	
		[Nm] ±5%	[in lbs] ±5%			[Nm] ±5%	[in lbs] ±5%
M6	8.8	10	90	M22	8.8	470	4160
	10.9	14	125		10.9	670	5930
	12.9	17	150		12.9	780	6900
M8	8.8	23	205	M24	8.8	600	5310
	10.9	34	300		10.9	850	7520
	12.9	40	350		12.9	1000	8850
M10	8.8	46	410	M27	8.8	750	6640
	10.9	68	600		10.9	1070	9470
	12.9	79	700		12.9	1250	11060
M12	8.8	79	700	M30	8.8	1000	8850
	10.9	117	1050		10.9	1450	12830
	12.9	135	1200		12.9	1700	15050
M14	8.8	125	1100	M33	8.8	1400	12400
	10.9	185	1650		10.9	1950	17250
	12.9	215	1900		12.9	2300	20350
M16	8.8	195	1725	M36	8.8	1750	15500
	10.9	280	2500		10.9	2500	22150
	12.9	330	2900		12.9	3000	26550
M18	8.8	245	2200	M39	8.8	2300	20350
	10.9	350	3100		10.9	3300	29200
	12.9	410	3600		12.9	3800	33650
M20	8.8	350	3100				
	10.9	490	4350				
	12.9	580	5150				



11.2 CENTA data sheet D004-900

Declaration of incorporation according to the EC Machinery Directive 2006/42/EC, Appendix II B

Manufacturer:

**CENTA Antriebe
Kirschey GmbH**
Bergische Strasse 7
42781 Haan / GERMANY

Contact:

Phone +49-2129-912-0
Fax +49-2129-2790
centa@centa.de
www.centa.info

We herewith declare that the **incomplete** machine

Product: Highly elastic CENTAMAX-S coupling

Model / series code: CM-S / 004S

Installation size: 120...18000

Design: all

Serial number: according to shipping documents, if applicable

- provided this is possible as far as the scope of supply is concerned - complies with the following basic requirements of the **Machinery Directive 2006/42/EC** Appendix I, subchapters 1.1.2, 1.1.3, 1.1.5, 1.3.2, 1.3.3, 1.3.4 und 1.5.4.

In addition, we declare that the special technical documents for this incomplete machine were compiled according to Appendix VII Part B and undertake to forward these to the market monitoring authorities by request via our "Documentation Department".

Commissioning of the incomplete machine is interdicted until the incomplete machine has been incorporated in a machine and the latter complies with the provisions of the EC Machinery Directive and the EC Declaration of Conformity according to Appendix II A is on hand.

The declaration is invalidated by every modification to the delivered parts.

Authorised representative for the compilation of the relevant technical documents:

i.A. J. Anderseck

by order of Gunnar Anderseck
(Authorised Person Documentation)

Declaration of incorporation was issued:

i.v. J. Exner

by proxy Dipl.-Ing. Jochen Exner
(Design Management)

Haan, 02.12.2009